



DSEControl



DEEP SEA ELECTRONICS PLC

DSEM840 Operator Manual

Document Number: 057-248

Author: Anthony Manton



Deep Sea Electronics Plc
Highfield House
Hunmanby
North Yorkshire
YO14 0PH
ENGLAND

Sales Tel: +44 (0) 1723 890099
Sales Fax: +44 (0) 1723 893303

E-mail: sales@deepseapl.com
Website: www.deepseapl.com

DSEM840 Operator Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo and the name DSEControl® are UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Revision History

Issue No.	Comments
1	Initial release of document

TABLE OF CONTENTS

Section	Page
1 INTRODUCTION.....	5
1.1 CLARIFICATION OF NOTATION.....	6
1.2 GLOSSARY OF TERMS.....	6
1.3 RELATED INFORMATION	7
1.3.1 TECHNICAL INFORMATION.....	7
1.4 SAFETY INSTRUCTIONS	8
1.4.1 GENERAL	8
1.4.2 INSTALLATION NOTES	8
2 SPECIFICATIONS	9
2.1 PROCESSOR.....	9
2.2 MEMORY.....	9
2.3 DC SUPPLY	9
2.3.1 FUSING	9
2.3.2 IGNITION (Pin A13)	9
2.4 ENVIRONMENTAL	10
2.5 USER INTERFACE	10
2.5.1 CONTROLS.....	10
2.5.2 DISPLAY	10
2.5.3 LED.....	10
2.6 REAL TIME CLOCK.....	10
2.7 INPUTS.....	11
2.7.1 DIGITAL INPUTS	11
2.7.1.1 DIGITAL	11
2.7.1.2 FREQUENCY.....	11
2.7.2 ANALOGUE INPUTS	11
2.7.2.1 VOLTAGE	11
2.7.2.2 CURRENT.....	12
2.7.2.3 RESISTIVE.....	12
2.7.2.4 RATIO METRIC	12
2.8 OUTPUTS.....	13
2.8.1 NEGATIVE SWITCHING.....	13
2.8.2 POSITIVE SWITCHING	13
2.9 COMMUNICATIONS	14
2.9.1 CAN	14
2.9.2 ETHERNET	14
2.9.3 USB	14
2.10 CAMERA INPUTS	15
3 INSTALLATION	16
3.1 DIMENSIONS AND MOUNTING	16
3.1.1 DIMENSIONS.....	16
3.1.2 FASCIA MOUNTING	17
3.1.3 RAM MOUNTING	18
3.2 FUSING	19
3.3 TYPICAL CONNECTION DIAGRAM	19
3.4 USER CONNECTIONS	20
3.4.1 CONNECTOR A	21
4 OPERATION	22
4.1 SYSTEM PAGES	22
4.1.1 NAVIGATION	22
4.1.1.1 PAGE SELECTION.....	22
4.1.1.2 OPTION SELECTION AND EDITING.....	22
4.1.2 DEVICE SETTINGS	23
4.1.2.1 NETWORK.....	23
4.1.2.2 CAN.....	24

4.1.2.3	BACKLIGHT	24
4.1.2.4	REAL TIME CLOCK	24
4.1.3	DEVICE ACTIONS	25
4.1.3.1	INSTALL SPLASH SCREEN	25
4.1.3.2	CLONE / RECOVER SELECTION	26
4.1.3.3	FORMAT MEMORY / DATA	27
4.1.3.4	KEYTEST	27
4.1.3.5	HISTORY	28
4.1.4	DEVICE INFORMATION	28
4.2	FIRMWARE UPDATE AND FILE SYSTEM OPERATIONS.....	29
5	CONNECTING TO CODESYS.....	30
5.1	START NEW PROJECT	30
5.2	ETHERNET TCP	31
5.3	ETHERNET UDP	32
5.4	CONFIGURE SETTINGS AND MONITOR THE DEVICE	34
5.4.1	DEVICE SETTINGS PARAMETERS	35
5.4.2	DEVICE SETTINGS I/O MAPPING	36
5.5	ADD INPUTS, OUTPUTS AND BUTTONS TO THE PROJECT	37
5.5.1	BUTTONS	38
5.5.1.1	BUTTON LOCATION	38
5.5.1.2	BUTTON SETTINGS	39
5.5.2	INPUTS AND OUTPUTS	40
5.5.3	DIGITAL INPUT PARAMETER CONFIGURATION	41
5.6	USING THE DISPLAY IN THE PROJECT	42
5.6.1	USING CUSTOM IMAGES ON THE DISPLAY	43
5.6.1.1	ADDING AN IMAGE POOL	43
5.6.1.2	ADDING IMAGES TO THE IMAGE POOL	43
5.6.1.3	USING THE IMAGE POOL ON THE DISPLAY	44
6	DSEM840 CODESYS ERROR CODES	45
6.1	DEVICE	45
6.2	ANALOGUE INPUTS	45
6.3	DIGITAL INPUTS	46
6.4	DIGITAL OUTPUTS	46
7	CABLES, CONNECTORS, HARNESSES AND SPARE PARTS	47
7.1	DSEM840 CONNECTOR HARNESS KIT (016-168)	47
8	MAINTENANCE AND WARRANTY	48
9	DISPOSAL	48
9.1	WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)	48

1 INTRODUCTION

This document details the operation and setup requirements of the DSEM840 Mobile Controller and Display, part of the DSEControl® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. DSE do not automatically inform on updates. Any future updates of this document are included on the DSE website at www.deepseapl.com

Observe the operating instructions. Non-observance of the instructions, operation not in accordance with use as prescribed below, wrong installation or incorrect handling seriously affects the safety of operators and machinery.




A robust metal case designed for chassis mounting houses the module. Connections are via locking plug and sockets.

The controller is supplied with no application program. The equipment manufacturer is responsible for creating and managing the application program and installing it in the controller. This is achieved using CODESYS V3.5 or C programming. Contact DSE Technical Support for further details.



1.1 CLARIFICATION OF NOTATION

Clarification of notation used within this publication.

	NOTE:	Highlights an essential element of a procedure to ensure correctness.
	CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
	WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

1.2 GLOSSARY OF TERMS

Term	Description
Application	The application is the program that allows the DSEM840 to control the machine it is connected to. The Application within the DSEM840 is designed and provided by the manufacturer of the complete machine.
Bootloader	The Bootloader is the program within the DSEM840 responsible for loading the Operating System.
CAN	Control Area Network. A high-speed data transmission system used extensively within the Automotive and Off-Highway industries.
CODESYS (Previously stylised as CoDeSys)	Integrated Development Environment for programming controller applications according to the international industrial standard IEC 61131-3. DSEM840 supports CODESYS V3.5
ECU	Electronic Control Unit. For example the DSEM840 device.
Firmware	The Firmware of the DSEM840 is the Operating System of the DSEM840 that reads and executes the Application program.
FSD	Full Scale Deflection. For example 0 mA to 20 mA is the Full Scale Deflection of a current sink input.
I/O	Input / Output. For example "The I/O is taken out to an external terminal strip in the user panel".
IDE	Integrated Development Environment. For example the CODESYS V3.5 application that runs on the host PC is an IDE.
Ixyyy	An Input, where x is the connector and yyy is the input number. For example IA003 means Input 3 on Connector A.
PLC	Programmable Logic Controller. Industrial computer used primarily for the automation of electromechanical machinery.
PWM PWMi	A digital signal is used to represent an analogue value by using Pulse Width Modulation. The mark-space ratio of a square wave changes to represent the value. Used for many control applications including proportional valves. PWM= Voltage control. PWMi = Current control.
Off-Highway	An industrial vehicle used primarily "off road". For example construction and farm machinery. A wider interpretation includes on road access platforms, emergency vehicles and other industrial machinery, used either on the road, or off road.
Pin	A male or female pin connection in a housing (plug or socket).
Qxyyy	An Output, where x is the connector and yyy is the output number. For example QA002 means Output 2 on Connector C.

1.3 RELATED INFORMATION

This document refers to, and is referred by the following DSE publications which are obtained from the DSE website: www.deepseapl.com or by contacting DSE technical support: support@deepseapl.com.

1.3.1 TECHNICAL INFORMATION

DSE Part	Description
055-198	DSEM640 Datasheet
055-222	DSEM840 Datasheet
053-188	DSEM840 Installation Instructions
057-244	DSEM640 Operator Manual

1.4 SAFETY INSTRUCTIONS

1.4.1 GENERAL

- These instructions are for authorised persons according to the EMC and low-voltage directives. The device must be installed, connected and put into operation by a qualified electrician.
- It is not permissible to open the controller or to modify or repair the controller. Modification or repairs to the wiring could result in dangerous malfunctions. Repairs to the controller must be performed by DSE. Contact your original equipment supplier in the case of malfunction.
- When the device is unpowered, ensure that no connection pins are connected to a voltage source. Thus, when the supply is switched off, the supply for the electronics, the power outputs and the external sensor supply must be switched off together.
- The customer is responsible for performing risk analysis of the mobile working machine and determining the possible safety related functions. The user is responsible for the safe function of the application programs created. If necessary, they must additionally carry out an approval test by corresponding supervisory and test organisations according to the national regulations.
- All connectors must be unplugged from the electronics during electrical welding and painting operations.

1.4.2 INSTALLATION NOTES

- Follow the instructions of the connector manufacturer, specifically with respect to preventing water from entering the device. See Section entitled *Cables, Connectors, Harnesses and Spare Parts* for details of DSE Part Numbers.
- M12 protection plugs (supplied) must be installed in both the USB and Ethernet interfaces to ensure IP67 rating when the connectors are not in use. Where IP protection is required when the interfaces are in use, suitable O-rings must be fitted.

2 SPECIFICATIONS

2.1 PROCESSOR

Description	Specification
NXP LPC4357 dual core	M4 & M0
Speed	200 MHz

2.2 MEMORY

Description	Specification
Flash	32 Mb
RAM	16 Mb


2.3 DC SUPPLY

Description	Specification
Operating Voltage (Pin A7)	6 V to 36 V
Maximum Current (Full Backlight, no External Loads)	<1000 mA at 24 V
Maximum Current (Full Backlight & Heater, no External Loads)	<1500 mA at 24 V
Maximum Current (After Controlled Shutdown With Ignition off)	<0.1 mA at 24 V

2.3.1 FUSING

Description	Specification
DC Supply (Pin A7) Supplies DSEM840 and High Current Outputs Fuse as Required by Output Loads (Pins A2, A3, A4, A5)	3 A Min (to supply DSEM840) 10 A Max.
Ignition (15) (Pin A13)	1 A Max

2.3.2 IGNITION (Pin A13)

 NOTE: Ignition (Pin A13) must be utilised correctly to enable / disable the application program. This ensures that logs and other changed parameters are stored when the Ignition is switched off.

Pin A7 is used to give a constant DC supply to the DSEM840, with the Ignition pin being used to energise and de-energise the ECU. Typically, this pin is controlled by an external ignition switch.

To stop the application, de-energise the Ignition pin. This allows the DSEM840 to store any changed parameters and logs before closing down.

2.4 ENVIRONMENTAL

Description	Specification
Operating Temperature	-30 °C to +65 °C (-22 °F to 149 °F)
Storage Temperature	-40 °C to +80 °C (-40 °F to 176 °F)
Degrees of Protection Provided by Enclosure (With All Mating Connectors Fitted)	IP67 (NEMA 6)

2.5 USER INTERFACE

2.5.1 CONTROLS

Description	Specification
Push Buttons	14

2.5.2 DISPLAY

Description	Specification
Size (Across Diagonal)	109 mm (4.3")
Size (W x H)	WQVGA (480 x 272)
Aspect Ratio	16:9
Type	Optically Bonded TFT
Lifetime	> 30,000 hours
Colour	24 bit
Splash Screen Image Type	Uncompressed Bitmap Image (BMP) 24 bit Colour 480 x 272

2.5.3 LED

Description	Specification
LED Type	Tricolour (Red, Blue, Green)

2.6 REAL TIME CLOCK

Description	Specification
Retention Type	Standard RTC.
Retention Time (Approx.)	5 years

2.7 INPUTS

2.7.1 DIGITAL INPUTS

2.7.1.1 DIGITAL

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Minimum Voltage For High Level	Configurable
Maximum Voltage For Low Level	Configurable

2.7.1.2 FREQUENCY

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Frequency Range	5 Hz to 30 kHz
Resolution	100 Hz at Maximum Frequency
Accuracy	400 Hz at Maximum Frequency
Minimum Voltage For High Level (Mark)	>4 V
Maximum Voltage For Low Level (Space)	<0.5 V

2.7.2 ANALOGUE INPUTS

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Reference Voltage Pins	A6
Reference Voltage	Programmable 0 V / 5 V / 10 V ±500 mV

2.7.2.1 VOLTAGE

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Configurable Ranges	0 V to 5 V 0 V to 10 V 0 V to 32 V
Input Resistance	≥7.5 kΩ
Sampling Rate	500 Hz

Voltage Measurement resolution and accuracy

Configured Range	Resolution (10 bits)	Accuracy (±1%) FSD
0 V to 5 V	0.007 V	±0.05 V
0 V to 10 V	0.017 V	±0.1 V
0 V to 32 V	0.035 V	±0.32 V

2.7.2.2 CURRENT

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Configurable Ranges	0 mA to 20 mA 4 mA to 20 mA
Input Type	Current sink only
Input Sink Resistance	100 $\Omega \pm 1\%$
Sampling Rate	500 Hz
Resolution	10 bits
Accuracy ($\pm 1\%$ Full Scale Deflection)	0.2 mA

2.7.2.3 RESISTIVE

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Measurement Range	0 Ω to 3400 Ω
Measurement Source Voltage	12 V maximum
Measurement Source Current	1 mA
Sampling Rate	500 Hz
Resolution	10 bits
Accuracy ($\pm 1\%$ Full Scale Deflection)	34 Ω

2.7.2.4 RATIOMETRIC

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Measurement Voltage Reference	Supply / Vref
Measurement Type	Ratio of input Pin to Reference
Accuracy ($\pm 1\%$ Full Scale Deflection)	0.36 V (based upon maximum supply voltage of 36 V)

2.8 OUTPUTS

2.8.1 NEGATIVE SWITCHING

Description	Specification
Applicable Pins	Pins A2, A3, A4, A5
Maximum Current	1 A selectable
Digital Output Active Low 'ON' State Maximum Voltage at Rated Current	< 100 mV
Digital Output Active Low 'OFF' State Leakage Current	<5 μ A at 24 V output supply

2.8.2 POSITIVE SWITCHING

Description	Specification
Applicable Pins	Pins A2, A3, A4, A5
Maximum Current	1 A selectable
Digital Output Active Low 'ON' State Maximum Voltage at Rated Current	<100 mV
Digital Output Active Low 'OFF' State Leakage Current	<120 μ A at 24 V output supply

2.9 COMMUNICATIONS

2.9.1 CAN


NOTE: CAN connections are NOT internally terminated. A complete CAN network must have 120 Ω terminators at each end of the network.

NOTE: Screened 120 Ω impedance cable specified for use with CAN must be used for the CAN links.
DSE stock and supply Belden cable 9841 which is a high quality 120 Ω impedance cable suitable for CAN use (DSE part number 016-030).

Description	Specification
Number of CAN Interfaces	2
Supported Protocols	J1939 CAN open Raw CAN
Supported Baud Rates	50 kbit/s, 100 kbit/s, 125 kbit/s, 250 kbit/s, 500 kbit/s, 800 kbit/s, 1 Mbit/s


2.9.2 ETHERNET

Description	Specification
Number Of Ethernet Ports	1
Supported Data Rates	10 Mbit/s / 100 Mbit/s, Duplex
Supported Protocols	MODBUS TCP CODESYS 3.5

M12 'D' Coded – 4 Pin Female	Pin	Description
	1	Tx+
	2	Rc+
	3	Tx-
	4	Rc-

2.9.3 USB

Description	Specification
Number of USB Ports	1
USB Version	2
Supported Speeds	Full Speed (12 Mbit/s)
Device Class	08 (Mass Storage)
Max Size	64 GB
Filing System	VFAT or FAT32

M12 'B' Coded – 5 Pin Female	Pin	Description
	1	5 V
	2	Data-
	3	Data+
	4	0 V
	5	Shield

2.10 CAMERA INPUTS


Description	Specification
Number of Camera Inputs	1
Connection Pins	A12 (signal), A18 (gnd).
Interface Type	Analogue (Composite) Video for PAL / NTSC

3 INSTALLATION

3.1 DIMENSIONS AND MOUNTING


3.1.1 DIMENSIONS

Description	Specification
Overall Dimensions (Height x Width x Depth)	208 mm x 131 mm x 56 mm (8.18 " x 5.14 " x 2.19 ")
Mounting Type	4 x mounting bolts or RAM mount.
Overall Weight	<1 kg (2.2 lb)



3.1.2 FASCIA MOUNTING


Description	Specification
Fascia Mounting Holes	Suitable for M5 bolts (0.3 " holes)
Fascia Mounting Hole Centres	180 mm x 70 mm (7.09 " x 2.76 ") See Diagram Below
Panel Cut-Out	163 mm x 98 mm (6.42 " x 3.86 ")
Fascia Mounting Bolt Material Recommendation	Steel or Stainless Steel
Fascia Mounting Bolt Tightening Torque to prevent distortion of the sealing gasket and subsequent seal failure / mechanical damage to the controller.	1.2 Nm Maximum (0.89 ft. lb Maximum)



3.1.3 RAM MOUNTING

DSE840 has four holes on the rear face, suitable for fitting of a RAM type mount. The spacing for the mounting holes is detailed in the image below.

Description	Specification
RAM Mounting Holes	Suitable for M5 bolts (0.3 " holes)
RAM Mounting Hole Centres	30 mm x 38 mm (1.19 " x 1.50 ")
RAM Mounting Bolt Material Recommendation	Steel or Stainless Steel
RAM Mounting Bolt Tightening Torque	4 Nm Maximum (2.95 ft. lb Maximum)




3.2 FUSING

The individual electric circuits must be protected in order to protect the whole system. Select appropriate fuses to protect the outputs being supplied.

Pin	Description	Comments	Recommended Fuse Size
A7	ECU Supply	Supplies DSEM840 CPU and Outputs	3 A to 10 A Max
A13	Ignition (15)		1 A Max


3.3 TYPICAL CONNECTION DIAGRAM



3.4 USER CONNECTIONS

NOTE: If a prewired connection cable is used, remove the cores with unused signal inputs and outputs. Unused cores, in particular core loops, lead to interference coupling that can influence the connected controller.

NOTE: USB and Ethernet connectors are coded differently. Do not try to force a connector into the wrong socket.



3.4.1 CONNECTOR A

NOTE: For details of fuse requirements, refer to section entitled *Fusing* elsewhere in this document.


NOTE: Ignition (Pin A13) must be utilised correctly to enable / disable the application program. This ensures that logs and other changed parameters are stored when the Ignition is switched off.

NOTE: Screened 120 Ω impedance cable specified for use with CAN must be used for the CAN links.
DSE stock and supply Belden cable 9841 which is a high quality 120 Ω impedance cable suitable for CAN use (DSE part number 016-030).

NOTE: CAN connections are NOT internally terminated. A complete CAN network must have 120 Ω terminators at each end of the network.

NOTE: Connect Camera using a single core conductor with screen (shield).

Terminology	Meaning
QA00x	Output
IA00x	Input
H	Output, High when active.
L	Output, Low when active.
AIN, FREQ	Input configurable to accept signals as positive digital, negative digital, 0 V to 5 V, 0 V to 10 V, 0 V to 32 V, 0 mA to 20 mA, 4 mA to 20 mA, ratiometric or resistive and frequency measuring

Connector A	Pin	Description	Comments
<p>(A Coded)</p> 	1	ECU Supply -ve	DC Supply negative for the DSEM840
	2	QA001	OUT H,L
	3	QA002	OUT H,L
	4	QA003	OUT H,L
	5	QA004	OUT H,L
	6	VREF +	VREF output for AIN
	7	ECU Supply +ve	DC Supply positive for the DSEM840
	8	CAN1 H	
	9	CAN2 H	
	10	IA001	AIN, FREQ
	11	IA002	AIN, FREQ
	12	Camera Signal	Analogue (Composite) video
	13	Ignition +ve (15)	Energises the ECU.
	14	CAN1 L	
	15	CAN2 L	
	16	IA003	AIN, FREQ
	17	IA004	AIN, FREQ
	18	Camera GND	Screen/GND for Camera

4 OPERATION

4.1 SYSTEM PAGES

The System Information and System Settings pages are accessed by pressing and holding any two of the fascia buttons during the power up (application of Ignition input with DC power supplied) of the DSEM840. Wait until *Entering Setup...* is displayed before releasing the buttons.

4.1.1 NAVIGATION

Within the System Pages, the following icons appear adjacent to the buttons to indicate their function.

Icon	Function	Description
ESC	Return	Return to a previous page.
◀▶▲▼	Navigate	Navigate through the available selections.
OK	OK / Accept	Accept/Edit the current selection, Save the value being edited.

4.1.1.1 PAGE SELECTION

Use the ◀ / ▶ buttons to move through the pages. Press **OK** to select the page. Press **ESC** to exit the editor and return to the main application.



4.1.1.2 OPTION SELECTION AND EDITING


While viewing the selected page, use the ◀ / ▶ buttons to move through the options, Press **OK** to select the option for editing.

While editing the selected parameter, use the ▲ / ▼ buttons to change the value, Press **OK** to save the change.

Press **ESC** to exit the editor.

4.1.2 DEVICE SETTINGS

This section allows access to the *Device Settings*.



4.1.2.1 NETWORK

This section allows selection of DHCP or Static IP address.

When connecting the device to a third party network, these settings must be made after consultation with the network manager.



Press **OK** to enable / disable *DHCP Option*.

Selecting *DHCP Option* instructs the device to obtain the network settings automatically from a DHCP server on the connected network. When unselected, the network options are user configured.

Press the **▲** / **▼** buttons to move through the options, Press **OK** to select the option for editing.

Press **ESC** to exit the editor.

While editing the parameter, use **◀** / **▶** buttons to move through the digits, use **▲** / **▼** buttons to change the value of the selected digit. Press **OK** to save the change. Press **ESC** to exit the editor.




4.1.2.2 CAN

This section allows configuration of the CAN interface parameters.

Press the ▲ / ▼ buttons to move through the options, Press **OK** to select the option for editing.


Selecting *Interface* and pressing **OK** cycles between the two CAN ports (0 & 1).



4.1.2.3 BACKLIGHT

This section allows adjustment of the LCD backlight brightness.


Use the ◀ / ▶ buttons to change the brightness, Press **OK** to save the change. Press **ESC** to exit the editor.



4.1.2.4 REAL TIME CLOCK


Allows the setting of the Real Time Clock and Calendar.

While editing the parameter, use the ◀ / ▶ buttons to change between fields and ▲ / ▼ buttons to change the highlighted value. Press **OK** to save the change. Press **ESC** to exit the section.



4.1.3 DEVICE ACTIONS

Allows selection of device actions.



4.1.3.1 INSTALL SPLASH SCREEN

DSEM840 supports the display of a *Splash Screen* at power up of the device. This is typically used to display the OEM logo image.

The device Password is required (when enabled) to allow Splash Screen installation.

For details of the supported USB memory stick and image type, see the section entitled *Specifications* elsewhere in this document.


Press the ▲ / ▼ buttons to select the required file, Press **OK** to apply it.
Press **ESC** to exit the section.



4.1.3.2 CLONE / RECOVER SELECTION

The device Password is required (when enabled) to allow Clone or Recover operations.

Press the ▲ / ▼ buttons to select the required function, Press **OK** to access it. Press **ESC** to exit the section.




CLONE

This section is used to create a backup file of the device, selecting the elements to backup.

This file may then be used to recover the device, or create *Clones*, sending the file to other devices.

Press the ▲ / ▼ buttons to select the required section to Clone, Press **OK** to action it.

Ensure the USB device used to store the Clone file(s) is connected to the controller. Press **ESC** to exit the section.



RECOVER

NOTE: The *Recover* process replaces files on the target device and may change the Application of the device.

This section is used to recover the device from a previously stored Clone (backup) file.

Ensure the USB device containing the file(s) to Recover is connected to the controller. All applicable files are listed.

Press the ▲ / ▼ buttons to select the required file, Press **OK** to apply it. Press **ESC** to exit the section.




4.1.3.3 FORMAT MEMORY / DATA

NOTE: The *Format* process deletes files on the target device and may change the operation of the device.

Select which memory area to Format.

Press the ▲ / ▼ buttons to select the required function, Press **OK** to access it. Press **ESC** to exit the section.




4.1.3.4 KEYTEST

This section allows the devices fascia buttons to be tested.


Press the keys and rotate the encoder to receive feedback of their operation.

To exit the Keytest, release all buttons for five seconds.




4.1.3.5 HISTORY

Used to display a log of the date of certain actions.
Press **ESC** to exit the section.



4.1.4 DEVICE INFORMATION

This section shows the *Device Information*.



4.2 FIRMWARE UPDATE AND FILE SYSTEM OPERATIONS

 **NOTE:** The *Format* and *Load from USB* process deletes files on the target device and may change the operation of the device.


This section allows the memory areas to be formatted (erased) and new firmware (DSEM840 operating system) to be installed.

- Remove Ignition from the DSE840.
- Press and hold any three buttons. Reapply Ignition until the DSE870 indicates that it is *Entering Flash / Recovery*. Now release the buttons to enter the Boot Menu.

Press ◀ / ▶ / ▲ / ▼ buttons to select the required option.

Press **OK** to access the selected function.

Press **ESC** to exit the section.





5 CONNECTING TO CODESYS

DSEM840 communicates with, and is programmed by, the CODESYS V3.5 Integrated Development Environment (IDE).

5.1 START NEW PROJECT

To begin, start a new project as shown.








5.2 ETHERNET TCP

NOTE: If the IP address of the device is not known, see the section entitled *Ethernet UDP* elsewhere in this document.

With the DSEM840 connected to the same Ethernet network as the PC, Select *Device | Communication Settings* in the CODESYS V3.5 IDE.








5.3 ETHERNET UDP


NOTE: If the IP address of the device is known, connection may also be achieved manually as detailed in the section entitled *Ethernet TCP* elsewhere in this document.

With the DSEM840 connected to the same Ethernet network as the PC, Select *Device | Communication Settings* in the CODESYS V3.5 IDE.




NOTE: A device in *Setup* mode is not discoverable by the Scan.





5.4 CONFIGURE SETTINGS AND MONITOR THE DEVICE





See the following subsections for details of the Device Settings pages.

5.4.1 DEVICE SETTINGS PARAMETERS

...and then select *Device Settings Parameters*...

...and then expand *New Ethernet Configuration* by clicking the + symbol.




Parameter	Type	Value
New Ethernet Configuration		
Save Config	Enumeration of USINT	No
IP Mode	Enumeration of USINT	No
WebConfig Port	UDINT	8080
IP Address		

After making changes, choose *Yes* in the *Save Config* section to save the changes made when the project is downloaded to the DSEM840 device.

5.4.2 DEVICE SETTINGS I/O MAPPING

This page is used to monitor the device, and if required, to map the monitored values to program variables.



Device Settings x

Device Settings Parameters

Device Settings I/O Mapping

Status

Information

Find

Variable	Mapping	Channel	Address	Type	Unit	Description
Error Code			%IW0	UINT		Error Code: Check Manual for more information
Device Temperature			%ID4	REAL	0.01°	Value of the Device Temperature
Battery Voltage			%IW8	UINT	mV	Battery Voltage
Ignition Switch			%IX10.0	BIT		Ignition Switch
Voltage Reference			%IW12	UINT		Voltage Reference Configuration
Backlight			%QW0	UINT		Backlight Level
Keyboard Backlight			%QW2	UINT		Keyboard Backlight Level

Error Code is a bit field, detailed in the section entitled DSEM840 CODESYS Error Codes elsewhere in this document.

5.5 ADD INPUTS, OUTPUTS AND BUTTONS TO THE PROJECT

Right-Click Device...

And select Add Device.

Select Deep Sea Electronics

Name	Vendor	Version	Description
Miscellaneous			
M840 Buttons	Deep Sea Electronics	1.0.0.0	M840 Buttons
M840 Camera	Deep Sea Electronics	1.0.0.0	M840 Camera
M840 Inputs	Deep Sea Electronics	1.0.0.0	M840 Inputs
M840 Outputs	Deep Sea Electronics	1.0.0.0	M840 Outputs

Select the device to add...

And click Add Device.

Add other devices if required, then click Close when finished.

Add Device **Close**

(You can select another target node in the navigator while this window is open)

5.5.1 BUTTONS


5.5.1.1 BUTTON LOCATION

The below image shows the location of the buttons along with their default names within the CODESYS environment.




5.5.1.2 BUTTON SETTINGS

Double-Click the Button to configure the *Hold Time* and variable mappings.




Click *Parameters* to edit the *Hold Threshold*



Parameter	Type	I...	I...	Unit	Description
Hold Threshold	UINT(1..32000)	50	50	ms	Threshold for Holding

Parameter	Description
Hold Threshold	Amount of time (in milliseconds) that the button must be pressed before it is considered 'held down'.



Click *Mapping* to view and edit the variable mapping.




Variable	Mapping	Channel	Address	Type	Unit	Description
State			%IX14.0	BIT		State of the Input
Held			%IX14.1	BIT		Value after Hold time
HoldTime			%IW16	UINT	ms	Button Hold Time

Parameter	Description
State	Indicates if the button is pressed (1) or not pressed (0).
Held	Indicates if the button has been held for longer than the duration of the <i>Hold Threshold</i> (1) or not (0).
Hold Time	The amount of time (in milliseconds) that the button has been pressed for (zero if not currently pressed).

5.5.2 INPUTS AND OUTPUTS




5.5.3 DIGITAL INPUT PARAMETER CONFIGURATION



Parameter	Description
Active Mode	Active High: The input connects to the positive supply rail when activated. Active Low: The input connects to the negative supply rail when activated.
Resistor	Float: The input is floating when no connection is made. Used where the external sensor (NPN Sinking or PNP Sourcing type) has an integrated pull-up or pull down resistor. Pull Up: An internal pull up resistor biases the input to the positive supply rail when no connection is made. Commonly used with NPN (Sinking) type switched sensors and volt-free contacts. Pull Down: An internal pull down resistor biases the input to the negative supply rail when no connection is made. Commonly used with PNP (Sourcing) type switched sensors and volt-free contacts.
Higher Threshold	For <i>Active High</i> inputs, the input is detected as being active when above this threshold with respect to the negative supply rail.
Lower Threshold	For <i>Active Low</i> inputs, the input is detected as being active when below this threshold with respect to the negative supply rail.

5.6 USING THE DISPLAY IN THE PROJECT


CODESYS 3.5 includes the facility to design and manipulate the LCD of the device. While the operation of the CODESYS environment is detailed within the CODESYS online document, this section provides a quick-start guide to using the *Visualisation* component of CODESYS 3.5.




5.6.1 USING CUSTOM IMAGES ON THE DISPLAY

Many applications require custom images to be placed on the DSEM840 display. This is controlled using an *Image Pool* within CODESYS. The Image Pool acts as a container for the images, which are then selected for display.

5.6.1.1 ADDING AN IMAGE POOL



5.6.1.2 ADDING IMAGES TO THE IMAGE POOL



Continued overleaf...

Right-Click the empty line and select *Insert Image*.

Then Double-Click the empty space under *File name* and click ...

Browse to the image on your computer...

And select how the image is stored in the project.

Click OK when done.

Example entries in the *Image Pool*.

ID	File name	Image	Link type
0			

ID	File name	Image	Link type
DSE	DSE.jpg		Embedded
CONTROL	control.PNG		Embedded

5.6.1.3 USING THE IMAGE POOL ON THE DISPLAY

Entries within the Image Pool are automatically detected by the CODESYS Visualisation Toolbox and are available for placing on the Visualisation.

Select *Image Pool* in the Visualisation Toolbox

Example entries in the *Image Pool* ready for placing on the Visualisation.

ID	File name	Image	Link type
DSE	DSE.jpg		Embedded
CONTROL	control.PNG		Embedded

6 DSEM840 CODESYS ERROR CODES

DSEM840 returns error codes to CODESYS when appropriate. Individual bits are set within the returned value to indicate one or more error conditions. This can be mapped to a variable if required and is available to view within CODESYS under the *Device Settings I/O Mapping* as shown below.

Device Settings Parameters

Device Settings I/O Mapping

Status

Information

The bus is not running. The shown values might not be valid.

Error Code is a bit field, detailed below.

Channels

Variable	Mapping	Channel	Address	Type	Current Value	Prepared Value	Unit	Description
		Error Code	%IW18	UINT	120			Error Code: Check Manual for more information
		Device Temperature	%ID10	REAL	18.2		°C	Value of the Device Temperature
		Battery Voltage	%IW22	UINT	15024		mV	Battery Voltage
		Supply Voltage 1	%IW23	INT	247		mV	Supply Voltage 1
		Supply Voltage 2	%IW24	INT	274		mV	Supply Voltage 2
		Supply Voltage 3	%IW25	INT	185		mV	Supply Voltage 3
		Supply Voltage 4	%IW26	INT	301		mV	Supply Voltage 4
		Ignition Switch	%IX54.0	BIT	TRUE			Ignition Switch
		Program Enable	%IX54.1	BIT	TRUE			Program Enable
		Voltage Reference	%IW28	INT	-1217		mV	Voltage Reference

Examples:

A *Device* error value of 120 (01111000 in binary) indicates that all four *Output Supplies* are *Under Voltage*.

A *Device* error value of 2 (00000010 in binary) indicates *Over Temperature*.

6.1 DEVICE

MSB	Bit						LSB
8	7	6	5	4	3	2	1
Output Reference Outside Limits	Reserved	Reserved	Reserved	Reserved	Under Voltage Supply	Over Temperature	Error

6.2 ANALOGUE INPUTS

Input Configuration	MSB	Bit						LSB
	8	7	6	5	4	3	2	1
Digital	Invalid Parameter	Reserved	Reserved	Invalid Threshold	Reserved	Reserved	Reserved	Error
Voltage	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Over Range	Inverted Input (<10 mV)	Error
Current	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Over Range	Wire Break (<4 mA)	Error
Resistance	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Over Range	Reserved	Error
Ratiometric	Invalid Parameter	Reserved	Invalid Reference	Reserved	Reserved	Over Range	Reserved	Error

6.3 DIGITAL INPUTS

Input Configuration	Bit							
	MSB 8	7	6	5	4	3	2	LSB 1
Digital	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Error
Frequency	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Freq Over Range	Reserved	Error

6.4 DIGITAL OUTPUTS

Output Configuration	Bit							
	MSB 8	7	6	5	4	3	2	LSB 1
Digital	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Error

7 CABLES, CONNECTORS, HARNESSES AND SPARE PARTS

Description	DSE Part	Manufacturer Part	Manufacturer
DSEM840 Connector A	007-850	DT16-18SA-K004	TE / Deutsch
Connector Pin Crimp (0.5 mm ² to 1.0 mm ²)	N/A	0462-201-16	TE
Connector Pin Crimp (2 mm ²)		0462-209-16	TE
DSEM840 Connector Harness Kit	016-168	N/A	DSE
M12 to Ethernet Cable	016-160	VS-M12MS-IP20-93R-L1/2	Phoenix
M12 to USB Cable	016-161	N/A	DSE
Belden 9841 (CAN Cable)	016-030	9841	Belden
Panel Mounting Sealing Gasket	020-602	N/A	DSE

7.1 DSEM840 CONNECTOR HARNESS KIT (016-168)

DSE Part 016-168 consists of a cable with connector fitted at one end, with cable marking to identify the wires at the other end.

	Connector A
Assembly Ident	007-850
AMP Connector	DT16-18SA-K004
No of Connections	18
Wire size	0.5 mm ² (AWG 20)
Wire Colour	Black
Wire Idents	1 to 18
Connector Pin Crimp (0.5 mm ² to 1.0 mm ²)	0462-201-16
Connector Pin Crimp (2 mm ²)	0462-209-16

8 MAINTENANCE AND WARRANTY

The device is *Fit and Forget*. As such, there are no user serviceable parts within the controller. In the case of malfunction, you should contact your original equipment manufacturer (OEM).

DSE Provides limited warranty to the equipment purchaser at the point of sale. For full details of any applicable warranty, refer to the original equipment supplier (OEM).

9 DISPOSAL

9.1 WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)

If you use electrical and electronic equipment you must store, collect, treat, recycle and dispose of WEEE separately from your other waste



This Page is Intentionally Blank

This Page is Intentionally Blank